

Dip sw. indstilling for

JK310 090703

Dip bank 1			1	2	3	4	5	6	7	8
Hopper værdi	Hopper 1	Hopper 2								
	-	20	ON	ON	ON	ON				
	-	10	ON	ON	ON	OFF				
	-	5	ON	ON	OFF	ON				
	-	2	ON	ON	OFF	OFF				
	-	1	ON	OFF	ON	ON				
	20	20	ON	OFF	ON	OFF				
	10	10	ON	OFF	OFF	ON				
	5	5	ON	OFF	OFF	OFF				
	2	2	OFF	ON	ON	ON				
	1	1	OFF	ON	ON	OFF				
	20	10	OFF	ON	OFF	ON				
	20	5	OFF	ON	OFF	OFF				
	20	1	OFF	OFF	ON	ON				
	10	5	OFF	OFF	ON	OFF				
10	1	OFF	OFF	OFF	ON					
5	1	OFF	OFF	OFF	OFF					
Veksel mode	Veksel op(2x5 = 10)						ON			
	Straks udbetaling						OFF			
Læser mode	Binær (15 kanal)							ON		
	Standard(4kanal)							OFF		
Hopper tom mode	LowLevel								ON	
	TimeOut								OFF	
€-kurs (kun binær)	7,2 kr									ON
	7,0 kr									OFF

Dip bank 2			1	2	3	4	5	6	7	8
Seddel tabel (kun std mode)	SEK	se tabel	ON							
	DKK		OFF							
Tæller	Ikke aktiv			ON						
	Aktiv			OFF						
Tæller faktor	1:10				ON					
	1:1				OFF					
LowLevel reset mode	Reset ved sluk-tænd					ON				
	Reset ved opfyld					OFF				

Seddel værdi	Std DKK	Std SEK	Binær
10			Kanal 1
20		Kanal 1	Kanal 2
50	Kanal 1	Kanal 2	Kanal 3
100	Kanal 2	Kanal 3	Kanal 4
LockOut			Kanal 5
200	Kanal 3		Kanal 6
500	Kanal 4	Kanal 4	Kanal 7
1000			Kanal 8
5€			Kanal 9
10€			Kanal 10
20€			Kanal 11
50€			Kanal 12

Mønt værdi	
1 kr	Kanal 1
2 kr	Kanal 2
10 kr	Kanal 4
20 kr	Kanal 5
5 kr	Kanal 6

Fejlkode for JK310

Hvis lysdioderne er monteret, så vises koden ved antal blink fra den røde diode i døren, når den grønne lyser fast.

Antal blink	Fejl	Årsag	Afhjælpes med
1	Hopper sw fejl	- mønt sidder fast i udgangen. - Hopper defekt.	Ryst hopperen. Udskift hopperen
2	Overflow fejl	Inter registerfejl	Genstart veksleren.
3	Hopper udbet fejl	Udbetalt for mange mønter	Udskift hopperen eller JK310
4	Mønt/seddel sw fejl	Forkert puls fra indk. ell. læser	Genstart, omk/udsk indk/læser
5	Timeout	For lang tid mellem mønter	Påfyld hopper - genstart.
6			
7			
8			